







Camteq Proshot Dual - Quick Start Guide v0.1

Take a Survey

1. With handset close to probe, press .
2. Default hole ID name is shown on display. Use buttons to edit hole ID - left and right to select character/number and up or down to change letter / number.
3. Press .
4. Handset will establish connection with probe and display will indicate that survey has started. The display will also prompt operator to use the Take Measurement button to take a shot and press Recover Data once the surveying is completed (and probe retrieved).
5. Once probe is at desired depth, press .
6. Default depth for survey is shown on display. Use buttons to edit depth as required - left and right to select number and up or down to change number.
7. Press .
8. Wait while measurement is taken.
Note: Probe must be kept stationary during this time or survey results will be affected.
9. Once handset indicates the shot has been taken (returns to same screen as shown at step 4), move probe to next depth and repeat steps 5 to 8 until all surveys are completed. (This assumes handset is in multi-shot mode)
10. Retrieve probe once surveying is completed.
11. Once probe is retrieved and is next to handset, press  to end survey and retrieve data from probe. Depending on how many surveys were taken, this may take some time.

Handset display will return to home screen to indicate that survey is complete and data recovered.

View Survey Data

1. Press .
2. Use left and right arrows to navigate between different surveys and depths.
3. Use up and down arrows to navigate through specific details of individual surveys.

Note: You need to navigate to the top level details of a survey to move to navigate through surveys.